



Use and Care Guide

Easy Connect


Dryer Duct to Wall Connector



TOOLS REQUIRED



Scissors



Phillips screwdriver

HARDWARE REQUIRED (NOT INCLUDED)




Screws (4)

Installation


1 SEPARATING THE CONNECTOR PIECES

- Separate the female wall connector from the male duct connector by pressing the two buttons on the sides and pulling the two pieces apart.




2 TRIMMING THE DUCT

- Use scissors or tin snips to cut the duct coming out of your wall so that it is flush with the wall surface.




3 SECURING THE CONNECTOR TO THE WALL

- Insert the female wall connector into the duct, and secure the connector to the wall with the appropriate screws depending on your wall material.




4 SECURING THE CONNECTOR TO THE DUCT

- Secure the end of the male duct connector onto the flexible duct coming from your dryer by turning the male duct connector counter-clockwise until it grips the duct firmly.




5 JOINING THE TWO CONNECTOR PIECES

- To complete the installation, push the male duct connector into the female wall connector until the buttons pop back into place.



6 SEPARATING THE CONNECTORS

- When access is needed to clean and maintain the ductwork, separate the connectors as in step 1.



Important Information

This product can be used with aluminum foil or semi rigid aluminum ducts.

Warranty

WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

WHAT IS NOT COVERED


This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit www.DundasJafine.com.


Mode d'emploi et d'entretien

ezconnect


Conduit de sècheuse vers raccord mural



OUTILS REQUIS



Tijeras



Destornillador Phillips

MATÉRIEL REQUIS (NON COMPRIS) :




Tornillos (4)

Installation


1 SÉPARER LES PARTIES DU RACCORD

- Séparez le raccord mural femelle du raccord de conduit mâle en appuyant sur les deux boutons sur le côté et en tirant les pièces de chaque côté.




2 COUPER LE CONDUIT

- Utilisez des ciseaux ou des cisailles pour couper le conduit qui dépasse du mur afin qu'il affleure à la surface du mur.




3 COUPER LE CONDUIT

- Insérez le raccord mural femelle dans le conduit et fixez le raccord au mur à l'aide des vis appropriées selon le matériau du mur.




4 FIXER LE RACCORD AU CONDUIT

- Fixez l'extrémité du raccord de conduit mâle au raccord flexible qui sort de la sècheuse en tournant le raccord de conduit mâle dans le sens antihoraire jusqu'à ce qu'il soit bien accroché au conduit.




5 JOINDRE LES DEUX PARTIES DU RACCORD

- Pour terminer l'installation, poussez le raccord de conduit mâle dans le raccord mural femelle jusqu'à ce que les boutons ressortent.



6 SÉPARER LES RACCORDS

- Lorsque vous avez besoin d'accéder au réseau de conduite à des fins de nettoyage et d'entretien, séparer les raccords tel qu'indiqué à l'étape 1.



Renseignements importants

Ce produit peut être utilisé avec des conduits en feuille d'aluminium ou semi-rigide.

Garantie

CE QUI EST COUVERT

Il est garanti que toute la marchandise est exempte de défauts de fabrication et de matériel pendant un an après la date de l'achat. Cela comprend l'usure normale et la défaillance des pièces. Le fabricant procédera au remplacement ou à la réparation, à son choix.

CE QUI N'EST PAS COUVERT

Cette garantie ne couvre que l'usure normale et la défaillance. Elle ne couvre aucune anomalie, défaillance ou défectuosité découlant de la mauvaise utilisation, de l'abus, de la négligence ou de la modification du produit. Les dommages et les anomalies infligés au produit par l'utilisateur ou une autre source extérieure et les manquements au respect des avertissements et les instructions ne sont pas couverts.

Pour obtenir de l'aide, rendez-vous à l'adresse www.DundasJafine.com.