









BT-90911H PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(6)X5 
(2)X1 	(7)X4  M6*22mm
(3)X1 	(8)X4  M6*30mm
(4)X1 	(9)X1 
(5)X1 