

## **CYCLONE BOOSTER FAN PLUS: OPERATING INSTRUCTIONS**

Step 1: For manual control simply set the switch to ON and the fan will be activated. Setting the fan to OFF will then turn it off.

Step 2: For automatic control set the switch to either HOT or COOL, depending on whether you want the fan to activate upon sensing cool air conditioned air or warm heated air.

Step 3: Tune the TEMPADJUST dial to your desired level of sensitivity. NOTE: This may take a few adjustments on your part to get the Booster Fan in-sync with your thermostat; generally the range is about ten degrees from most sensitive to least sensitive in either HOT or COOL mode. For example in HOT mode on the most sensitive setting the fan will automatically turn on when it senses even slightly heated air, whereas in the least sensitive setting the air would have to be heated significantly. Again, it may take a few adjustments to get the Cyclone Booster Fan in-sync with your thermostat or air conditioning system. For clarification, if the Booster Fan is set to HOT mode it will not turn on immediately with the furnace, rather it will turn on when all of the unheated air is out of the ducts and it begins to sense heated air. Once you have the Booster Fan Plus tuned to your thermostat you will never have to worry about it again. Just set it and forget it!

### **Cyclone Booster Fan Plus Limited Warranty (For customers to keep):**

North America Range Hoods Inc. (Hereunder called The Company”) provides a warranty that its products are free from defects in workmanship and materials for a period of one year from the purchase date of the original purchase (The original receipt and this warranty card must be provided.)

For warranty services please contact the dealer whom you purchased the product from or the address shown below:

The Company reserves the right to change product specifications without any notice.

**North America Range Hoods Inc.**  
**1361 Huntingwood Drive, Unit 16, Scarborough, Ontario, Canada, M1S 3J1**  
**Tel: 1-888-293-5662**

**<http://www.cyclonerangehoods.com>**

**Email: [info@cyclonerangehoods.com](mailto:info@cyclonerangehoods.com)**