


HOW TO CHOOSE THE RIGHT AIR CONDITIONER FOR YOUR ROOM

1 Measure Your Room



2 Match Room Size to BTUs

Room Size :	BTUs
200 SQ.FT. 10' x 20'	8,000
300 15' x 20'	10,000
400 20' x 20'	12,000
500 20' x 25'	14,000


FOR THE PERFECT FIT, BE SURE TO CHECK THESE REQUIREMENTS

Window Size for Duct Installation

Horizontal Duct Installation :



Vertical Duct Installation :



Electrical Requirements



- 115 Volts AC
- 15 Amps
- Draws 9.6 Amps
- Includes 70" grounded cord
- Weight : 70.5lbs.